

# XT-2000G Installation Guide

## Content

Product Overview .....	1
Installing the Unit .....	1
LED Status Indicators .....	1
Installing the Standard Starter Disable .....	2
Installing the Starter Disable with ECM .....	4
Tips on Installing .....	3

## Product Overview

The XT-2000G is a self-supporting tracking unit that requires only constant power and ground to operate. The unit contains two antennas: one for GPS data and the other for GSM/GPRS communication. You can easily install this unit under the dash of the vehicle for concealment.

## Installing the Unit

### Mounting the unit

To mount the unit, make sure the label side is facing the ground (down). Do not place the unit below a metal object as metal objects can interfere with the internal antennas' signals. Plastic, glass, and other materials do not cause interference with the signal.

### Powering up the unit

After attaching the wires and mounting the unit, power up the unit by connecting the harness. When powered up, the LED status indicators on the unit light up. See Table 1 below for descriptions on what these LED status indicators mean.

It may take up to five minutes to lock in a GPS signal. If you cannot obtain a GPS signal, wait for two more minutes, reposition the unit, and then try again.

## LED Status Indicators


Table 1 below describes the status of the unit based on the LED indicators.

**Table 1: LED status descriptions**

Color	Condition	Description
Green	Solid	No GPS signal

Color	Condition	Description
	Flashing	Good GPS signal
Blue	1 sec flash, 3 sec off	Good cellular coverage
	1 sec flash, 1 sec off	No cellular coverage

**Figure 1: LED status indicators**




## Installing the Standard Starter Disable

**To install the standard starter disable:**

1. Connect the starter disable relay to the 12V starter wire. Cut the wire into two parts, one connecting to the ignition switch, and the other connecting to the starter
2. Connect one part of the wire (connected to the ignition switch) to the red wire from the socket relay and then to the 12V supply.
3. Connect the white wire from the socket relay to the other part the cut wire (connected to the starter).
4. Connect the orange wire from the socket relay to the green wire from the harness device.

Figure 2 below provides a wiring diagram on how install the standard starter disable.

Figure 2: Five-wire harness with starter disable relay diagram



## Tips on Installing

To ensure proper installation of the XT-2000G unit, follow the listed recommendations:

- Ground the unit directly to the frame. Do not use small screws not attached to the frame for grounding.
- Splice the wires correctly and properly insulate them. Do not splice carelessly and without proper insulation.
- Make sure the device and all wiring are secured. Do not let the device and wiring hang haphazardly.
- Make sure you have proper light sequence before closing the dash.
- Use a constant 12V power supply. Do not use a pulsating 12V power supply.
- Make sure the unit is mounted with the label side facing down.